



Part #954

8-25-2005

- STEP 1.** Slide the large neoprene bushings onto the bar, just around the bends.
- STEP 2.** Assemble end-links as shown, tighten nuts against rubber parts only moderately. The angle bracket is at the top with vertical side with small hole instructions for details on end-link assembly.
- STEP 3.** Position bar across and under suspension trailing struts, in front of rear axle, arms forward. End-links should be vertical up to frame rear point where frame starts to curve upward. Mark frame and drill with 3/8" drill bit, and attach.
- STEP 4.** Cover neoprene bushings on bar with bracket so that they locate on underside of trailing arm. Mark and drill with 3/8" drill bit. Attach to trailing struts.
- STEP 5.** Check all lock-nuts for tightness. Check clearance of bar assembly and other suspension parts.

**Note:** As we cannot supervise your installation or your driving, we cannot be held responsible for more than the cost of the kit.

**HARDWARE:**

2 RH 017	End-Links	2 RH 508	Bushings
2 RH 040	Brackets	6 RH 304	Lock-Nuts
2 RH 022	Angle Brackets	6 RH 214	Bolts

**DIRECTION N 954**

