

Flat Panels

For  IQ3 and UDX units.

Installation Help and Recommendations

- Flat Panels are a trim to fit mounting solution for your particular need and vehicle.
- The panels are designed to be universal in application.
- Each panel is made from ABS plastic and can be drilled, cut, filed, sanded, and trimmed.
- **CARE.....** should be taken to protect the surface area when working with the panel. Masking tape applied to the surface area is recommended.
- The Carbon Fiber and Brushed Aluminum finish are easily scratched if left unprotected when modifying the panel.
- A razor knife drawn across the edges of the Carbon Fiber and Brushed Aluminum panels will clean up the stringy material left when these types of panels are cut.
- To drill holes, use standard Hi-Speed steel drill bits or step bits and to cut holes for gauges use hole saws or circle cutters.
- To clean fingerprints, smudges, and other residues off the Carbon Fiber and Brushed Aluminum material use a mild soap (Dawn or Joy) or Rubbing Alcohol. **Absolutely, NO SOLVENTS!**
- To clean dust or grit use compressed air or a soft bristled brush. Do not wipe with a cloth until all dust/grit is blown off.

Note: The thru holes for the mounting studs are drilled large so the Racepak units will have a full range of motion for alignment in the pockets. Use the ¼” washers supplied, for securing the units in place.

Note: The Installation of this product is the sole responsibility of the user/installer, no specific Installation Instructions are provided. All liability rests on the user/installer of this product. **Take proper precautions to protect the finish of this panel while working with it.**

Flat Panels

For  IQ3 and UDX units.

Installation Help and Recommendations

- Flat Panels are a trim to fit mounting solution for your particular need and vehicle.
- The panels are designed to be universal in application.
- Each panel is made from ABS plastic and can be drilled, cut, filed, sanded, and trimmed.
- **CARE.....** should be taken to protect the surface area when working with the panel. Masking tape applied to the surface area is recommended.
- The Carbon Fiber and Brushed Aluminum finish are easily scratched if left unprotected when modifying the panel.
- A razor knife drawn across the edges of the Carbon Fiber and Brushed Aluminum panels will clean up the stringy material left when these types of panels are cut.
- To drill holes, use standard Hi-Speed steel drill bits or step bits and to cut holes for gauges use hole saws or circle cutters.
- To clean fingerprints, smudges, and other residues off the Carbon Fiber and Brushed Aluminum material use a mild soap (Dawn or Joy) or Rubbing Alcohol. **Absolutely, NO SOLVENTS!**
- To clean dust or grit use compressed air or a soft bristled brush. Do not wipe with a cloth until all dust/grit is blown off.

Note: The thru holes for the mounting studs are drilled large so the Racepak units will have a full range of motion for alignment in the pockets. Use the ¼” washers supplied, for securing the units in place.

Note: The Installation of this product is the sole responsibility of the user/installer, no specific Installation Instructions are provided. All liability rests on the user/installer of this product. **Take proper precautions to protect the finish of this panel while working with it.**