

# MSD INSTALLATION INSTRUCTIONS

## MSD Rotor, PN 8470 Replacement Rotor for PN 8473 and PN 8485 Distributors

### Parts Included:

1 - Rotor  
2 - Belleville Washers  
2 - 1/2" Phillips Head Screws

**WARNING:** Disconnect the battery during installation. When disconnecting the battery, always remove the negative cable first and install it last.

**IMPORTANT:** Use screws supplied with this rotor. They provide the necessary clearance for the magnetic pickup. It is recommended to apply blue threadlocker, or equivalent, to screws before installing.

Mark the location of the plug wires before removing them from the cap. Remove the cap and rotor. Install the new rotor being sure the round and square aligning pegs are lined up correctly on the advance plate. Install the Belleville washers with the **dome facing up** on the screws and tighten the rotor (Figure 1). Install the cap and plug wires.




Figure 1 Washer Installation.

MSD • WWW.MSDPERFORMANCE.COM • (915) 857-5200 • FAX (915) 857-3344  
© 2017 MSD LLC  
FRM34550 Created 03/17 Printed in U.S.A.

# MSD INSTALLATION INSTRUCTIONS

## MSD Rotor, PN 8470 Replacement Rotor for PN 8473 and PN 8485 Distributors

### Parts Included:

1 - Rotor  
2 - Belleville Washers  
2 - 1/2" Phillips Head Screws

**WARNING:** Disconnect the battery during installation. When disconnecting the battery, always remove the negative cable first and install it last.

**IMPORTANT:** Use screws supplied with this rotor. They provide the necessary clearance for the magnetic pickup. It is recommended to apply blue threadlocker, or equivalent, to screws before installing.

Mark the location of the plug wires before removing them from the cap. Remove the cap and rotor. Install the new rotor being sure the round and square aligning pegs are lined up correctly on the advance plate. Install the Belleville washers with the **dome facing up** on the screws and tighten the rotor (Figure 1). Install the cap and plug wires.




Figure 1 Washer Installation.

MSD • WWW.MSDPERFORMANCE.COM • (915) 857-5200 • FAX (915) 857-3344  
© 2017 MSD LLC  
FRM34550 Created 03/17 Printed in U.S.A.